



Code	Power	Feeding	Size	Protection	Body	IP Protection	IK Protection	Class	Power cable	Fixing
LONG PS2039X2-230	2 TF FLUORESCENT TUBES T5	39 W G5	920 x 130 x 29 mm	SCREEN IN TEMPERED GLASS	EXTRUDED ALUMINUM	P68	IK08	I	ABSENT	WITH HOOKS
MEDIUM PS2024X2-230	2 TF FLUORESCENT TUBES T5	24 W G5	620 x 130 x 29 mm	SCREEN IN TEMPERED GLASS	EXTRUDED ALUMINUM	IP68	IK08	I	ABSENT	WITH HOOKS

The ceiling light consists of a sturdy black anodised extruded aluminum profile. The aluminum body dissipates the heat produced by the electronic supply circuit and the fluorescent tube, considerably increasing their life.

The body of the product in Polymethylmethacrylate offers excellent resistance to acids, diluted alkaline solutions, fats and oils.

The molded polymer side parts are screwed directly to the extruded aluminium body, while the front of the ceiling is covered by the 4 mm tempered Pirex glass screen and perfectly sealed with polyurethane.

PS20 **2X24W**   
**2X39W** 

